














MARCA E MODELLO RADIOCOMANDO ORIGINALE	POSIZIONE DEI DIP SWITCH
<p>433.92 MHz</p> <p>BFT (433.92 MHz)</p>  <p>MITTO 2M - MITTO 4M MITTO B RCB2 - MITTO B RCB4 TRC1 - TRC2 - TRC4 KLEIO B RCA 2 - KLEIO B RCA4</p>	<p><input checked="" type="checkbox"/> RX MULTI 300-868 MHz? SÌ</p> 
<p>433.92 MHz</p> <p>CAME</p>  <p>TOP435</p>  <p>TOP434NA</p>  <p>TOP432N</p>  <p>TOP43M</p>	<p><input checked="" type="checkbox"/> RX MULTI 300-868 MHz? SÌ</p> 
<p>433.92 MHz</p> <p>CARDIN</p>  <p>S449 QZ1</p>  <p>S449 QZ2</p>  <p>S449 QZ3</p>  <p>S449 QZ4</p>  <p>S449 QZ2 GREEN</p>	<p><input type="checkbox"/> RX MULTI 300-868 MHz? NO</p>
<p>433.92 MHz</p> <p>CENTURION</p> 	<p><input checked="" type="checkbox"/> RX MULTI 300-868 MHz? SÌ</p> 